

SAFEMOD™

INSTALL INSTRUCTIONS

- 1) ENSURE RIFLE IS UNLOADED AND VERIFY CLEAR.
- 2) REMOVE FACTORY MAGAZINE CATCH & BUTTON
- 3) INSTALL SAFEMOD™ BUTTON THE SAME WAY YOU WOULD INSTALL MIL-SPEC BUTTON
- 4) INSERT MAGAZINE YOU WISH TO BE PERMANENTLY ATTACHED
- 5) THREAD SS 4-40 SET SCREWS INTO BUTTON UNTIL THEY BOTTOM OUT AND ARE TIGHT. YOU CAN USE THREADLOCKER BUT IT IS NOT NECESSARY
- 6) USE INCLUDED EPOXY TO BACKFILL THE HOLES BEHIND SET SCREWS FOR A PERMANENT SOLUTION
- 7) REASSEMBLE RIFLE AND FUNCTION TEST

NOTE: THIS PRODUCT HAS NOT YET BEEN EVALUATED BY THE NY STATE POLICE. WE CANNOT BE HELD RESPONSIBLE FOR A LAW ENFORCEMENT OFFICIAL'S MISINTERPRETATION OF THE LAW OR THE LEGALITY OF THIS PRODUCT.